

Simple Usage Tips for your Voice Activated Body Worn DVR

General Info.: The DVR camera will record until the internal battery is drained, until you turn it OFF, or until the memory is full. If it turns off due to battery drainage - it will automatically save your recorded video before it powers off. A full 2-3 hour charge of your key chain will allow for 1.5 to 2 hours of recording. You can use up to an 8GB Micro SD flash memory card.

(1) Press the Power button to power ON the DVR: Both the blue and red LEDs will illuminate and then the red light will disappear leaving only the blue light steady on – this is the standby mode.

(2) **Video:** Press and release the STOP/PLAY button on TOP of the DVR – you're now taking video while the red light is flashing slowly. Press the STOP/PLAY button again to stop and save your video.

(3) Voice Activated Mode: With the power ON and the blue light ON steady– press and release the Voice Activated Recording (VOX) button – the red light will begin to blink quickly. In this setting, a voice or a normally audible sound (above 50-60 decibels) makes the red light begin to blink slowly which shows you are recording in the voice activated mode. It will record for two minutes straight and then attempt to go into the dormant mode again after saving your file. The blue light will shine steady and the red light will blink quickly on as it begins this dormant mode. It will have already saved your previous file and the next sound above 50 – 60 decibels that it hears will trigger it to begin recording again. This process will continue to repeat itself until the flash memory is full or the battery power is drained. Each new recording will be saved as it's own video file.

NOTE: Each press of the MODE button switches the DVR from NORMAL to VOICE ACTIVATED MODE.

To Set the Time and Date Stamp: Your Body Worn DVR Camera is capable of marking your recordings with a Time and Date Stamp - great for evidence. Connect your DVR to your PC's USB port – find the correct drive letter that it has been assigned – and open up the memory to the DVR. Then, go to our FAQ page at www.spy-tronix.com/FAQs.html Download our (.txt) template for the DVR time setting and save it directly into the memory of your DVR. Open it up and enter in YOUR current date and time in the form of: YYYY-MM-DD HH:MM:SS for example 2008-08-14 14:25:00.

➔ Then, after you've correctly typed your current time and date in the format above, save this file and close it. Correctly remove the DVR from the computer. Turn the DVR OFF and then back ON. It should now record with the correct time stamp. You will also notice that the userconfig.txt file is now missing from the top level of your DVR.

Watching your videos: Your videos will record in .AVI format and they should playback well in your favorite PC player (i.e., Windows Media Player). If you have any trouble playing the video files, then please download the free player at: www.videolan.org. It is safe, free, easy to use, and we've found it to be very dependable in playing the most modern types of video and audio files.

USB Mass Storage: Carry up to 8GBs of your most important files with you. Each DVR has a built in USB plug that connects directly to your PC. You just plug it into the USB port and it appears as a removable drive. There is no other device to carry. You can drop and drag your files just like you do on your computer. Not only that, but you can store all of your typical PC files on your Body Worn DVR: Word documents, Excel files, image files, etc.

➔ ALWAYS RECORD LEGALLY – CONSULT YOUR ATTORNEY IF EVER IN DOUBT.

The Geek Factor, LLC.
www.spy-tronix.com
www.thegeekfactor.com
www.the-geek-factor.com

(2009 – all rights reserved)

