

Simple Usage Tips for your “Button Stick Camera”

Congratulations on your purchase of our Mini Button Stick Camera! You’ll find that it’s incredibly easy to operate the video/audio quality is great for all of your covert video needs. We suggest that you practice with your Button Stick Camera prior to the first time you will really need to use it. First practice without the magnetic ring – then practice with the magnetic ring. In general, the magnetic ring acts just the same as if you were pressing the ON / OFF button manually. It is an incredible device!

CHARGING and LIGHT LEVEL: Connect the camera to the included USB port and then connect it to your computer or our optional power adapter if you purchased one; allow your camera to charge for about 2 full hours before you use it the first time. Subsequent charges need only be for 1-2 hours max. Your camera will work best for you when you record video or take images in a well lighted environment.

RECORDING VIDEO WITH AUDIO: First, slide the Photo/Video switch (bottom back of camera) to the RIGHT SIDE (LEFT = PHOTO / RIGHT = VIDEO). When your camera is OFF – you will not see any LED light at the top (back) of the camera. Press and HOLD the Power button (with your finger nail) for 3-5 seconds (you will hear it “click” when the button is fully pressed), it will turn ON. The yellow light will illuminate momentarily and then the blue light will be steady ON. You are recording Video as soon as the Blue light illuminates. Press the ON/OFF switch one time to STOP and save your video; the Yellow light will illuminate showing that the video file has been saved and you are in the STANDBY mode. Press the ON/OFF button again to start another video file – or you can use the magnetic ring to accomplish the steps above. Each time the magnetic ring passes by the lens of the camera – it acts just the same as a button press of the ON/OFF switch. Also, holding the magnetic ring near the lens for 3-5 seconds will power ON/OFF the camera.

TAKING STILL IMAGES: First, slide the Photo/Video switch to the LEFT side. Press and HOLD the Power button for 3-5 seconds to turn the camera ON. The yellow light will illuminate momentarily and then the blue light will be steady ON. You are in the STANDBY mode for taking photos. Press the ON/OFF switch one time to TAKE and save a photo; the Yellow light will briefly illuminate showing that the photo file has been saved and then the blue light will shine again. Press the ON/OFF button again to take another photo file – or you can use the magnetic ring to accomplish the steps above. Each time the magnetic ring passes by the lens of the camera – it acts just the same as a button press of the ON/OFF switch. Too easy!

File Playback: Use the included USB cable to connect your Button Stick Camera to your PC or Laptop USB port. Your computer should recognize the device automatically. When you open the window for your Button Stick Camera – you’ll see all of your saved files. They’re saved in “.AVI” file format which can be viewed with your Windows Media player that is probably already installed on your PC. If you do not have it installed on your PC, then please know that any media player that recognizes .AVI files will work. If you cannot play the files on your computer – then please go to www.videolan.org to download their free media player. That’s it! After just a few uses and a little practice, your Button Stick Camera and the magnetic control ring will become second nature to you. Enjoy!



The Geek Factor, LLC.
www.spy-tronix.com
www.thegeekfactor.com
www.the-geek-factor.com