

## Pen Recorder with FM Radio / Helpful user tips



**NOTE:** You can either PLAYBACK your messages on your computer, or by using the included headphones connected directly to your Pen Recorder (best sound quality). You must always keep at least (1) ONE MP3 file on your Pen Recorder for it to operate properly. Use the steps below in addition to the instructions included with your Pen Recorder.

\* You must record legally within your local, state, and federal laws; The Geek Factor, LLC., will NOT be held responsible for your misuse or violation of applicable recording laws. When in doubt about the legality of your intended recording scenario, seek the advice of an attorney BEFORE you begin to record. \*\* Charge pen for 3 hours prior to using.

---

### Your Pen Recorder's LED Lights and their meanings:

POWER ON = PRESS AND HOLD ►| for more than 2 seconds

POWER OFF = From any mode / PRESS AND HOLD ►| for more than 5 seconds

MP3 PLAY Mode = Green light BLINKS @ 1.5 second duration

MP3 PAUSE Mode = Green light ON STEADY (shuts off automatically in 15 seconds without button presses)

RECORD Mode (waiting) = Blue light ON STEADY (shuts off automatically in 15 seconds without button presses)

RECORD Mode (recording) = Blue light BLINKS @ 1 second duration

FM MODE = Blue light ON constant along with the Green light BLINKING @ 1.5 second duration

**REMEMBER:** Should you get lost in your button presses, or not be able to operate the mode that you want, simply POWER OFF your pen recorder and start again from the beginning.

---

### Steps to Record QUICKLY:

1. With the Pen Recorder's Power OFF - PRESS and HOLD ►| for more than 2 seconds
2. With the green light flashing, quickly PRESS AND RELEASE the ( FM ) button (the blue light will illuminate steady)
3. With the Blue light ON STEADY - Press the ►| button one time "quickly" and then release it.
4. The blue light will flash - you are now recording.
5. To STOP recording - Press the ( ►| ) button again "quickly" and then release it. (the blue light will illuminate steady)
6. The next time you press the RECORD button, you will begin to record a new message....see step 5 to stop recording.

### Steps to Playback your messages:

1. Follow STEPS 1 and 2 ABOVE to get into the RECORD Mode.
2. With the blue light ON STEADY, quickly PRESS AND RELEASE the ( - VOL ) button.
3. Your recorded messages should now be playing.